

Magnetic drive eliminates product contamination.

Call International Reactor!

Another solution for our customers!

Customer: Medical Technology Company
Location: Tennessee

A 5 gallon reactor with two zone electric band heaters controlled by a PID controller. Magnetic drive to eliminate product contamination that could come from seal lubrication leakage if a mechanical seal was used. Control cabinet mounted to reactor stand so that all controls are close at hand. Actuated flush bottom ball valve for discharge final product. Electropolished for easy cleanability.



How can we help meet your needs?

**International
Reactor
Corporation**



521 Kiser Street
Dayton, OH 45404-1641
Phone: (937) 224-4444
Fax: (937) 224-4434
E-mail: sales@irc-reactors.com